



Instructions DN-2,0 mm fitting.

The tube should be cut to the required length from the coil, using the special cutting tool

First, slide the brass sleeve, and next, the brass nut onto the tube.

Next, fully push the brass spigot (nipple) into the inner tube, taking care not to crack the hose. Please push the nipple till the stopper touch hose. The tube has to be square with the nipple's flat face.

Now position the crimping tool jaws over the brass sleeve and crimp. Please hold the end of the brass sleeve flush with the face of the tool jaws according to sketch above. The handlebars of the tool should be closed until the tool locking mechanism is released automatically.

The connection is now ready for use. Depending on the quality of the face of the fitting to make a connection with, one might decide not to apply a copper gasket.

